

# LARDIS

## What is a secondary control center?

With LARDIS and LARDIS:ONE, it is possible to send a status message to a so-called "secondary control center" (fixed number as destination) in addition to a status message to the control center. This makes it possible to send a message (status, text, position) in parallel to e.g. the own operations center or an command vehicle.

A status is only sent to the secondary control center when the regular status dispatch to the control center has been completely processed. This also concerns, among other things, a correct status confirmation or a Tetra-ACK.

Further information can be found in the documentation for the [LARDIS-ONE 2.x](#) or for the [LARDIS Manager](#).

Unique solution ID: #1104

Author: Tech. Support

Last update: 2023-02-10 16:03