

# LARDIS:ONE

## How do I configure a status confirmation?

If this is switched on, the corresponding icon appears for a sent status if the confirmation is stored correctly. The format of the confirmation can be determined and entered by comparing it with the incoming SDS confirmation.

If status messages have already been sent via the LARDIS:ONE, you will find corresponding confirmations in the [Setup](#) under "Status" -> "ACTIONS" -> "Export events".

Under the following link you will find a detailed description: [Configure status confirmation \(DE\)](#)

If you need help with this, please contact your installation partner.

Unique solution ID: #1081

Author: Tech. Support

Last update: 2023-02-10 15:53